




Take the BUD to an open place with access to water. Be aware of possible harm or damage caused by sharp and rough ground.



- **BUD Mannequin**
- **B** Air Pump




Remove water valve located at the bottom close too the ground. Begin water injection.



Inject as much water as possible to ensure the effectiveness of bouncing back.



Tip: Use the tube from air pump as water tube.



Remove air valve cap. Connect air pump to Make sure to stop pumping when the BUD by using the hose provided. Inflate with blue line has reach the red "MAX" zone. Over inflating can be dangerous.



Roll up the BUD starting from the


Put back the air cap before moving the BUD. Use side carry handles to move the BUD to the designated training area



Put everything back into the bag or designated box for storage.



slow speed pull and pushes. **Push and Pull Handle** 



Before packing up, remove the two valves to deflate and pour out the water. Maker sure the water tank is empty before rolling up.

